

Gesamthubhöhe = Hubhöhe + ca. 1.2m Aufbauniveau
Overall height = vertical outreach + approx. 1.2m installation height
Hauteur totale = portee verticale + env. 1.2m hauteur de pose

